



:

ANT-1-315-50	315	15	2,0	2,0	50		-	BNC/ SMA	
ANT-1-375-50	375	20	2,0	2,0	50		-	BNC/ SMA	
ANT-1-450-50	450	22	2,0	2,0	50		-	BNC/ SMA	
ANT-1-650-50	650	32	2,0	2,0	50		-	BNC/ SMA	
ANT-1-950-50	950	45	2,0	2,0	50		-	BNC/ SMA	

				( )					
ANT-1-1050-50	1050	50	2,0	2,0	50		-	BNC/ SMA	
ANT-1-1150-50	1150	60	2,0	2,0	50		-	BNC/ SMA	
ANT-1-1250-50	1250	60	2,0	2,0	50		-	BNC/ SMA	
ANT-1-1350-50	1350	65	2,0	2,0	50		-	BNC/ SMA	
ANT-1-1450-50	1450	70	2,0	2,0	50		-	BNC/ SMA	
ANT-1-1550-50	1550	75	2,0	2,0	50		-	BNC/ SMA	
ANT-1-2050-50	2050	100	2,0	2,0	50		-	BNC/ SMA	

ANT-1-2150-50	2150	100	2,0	2,0	50		-	BNC/ SMA	
ANT-1-2250-50	2250	110	2,0	2,0	50		-	BNC/ SMA	
ANT-1-2350-50	2350	120	2,0	2,0	50		-	BNC/ SMA	
ANT-2-315-30 «            »	315	10	2,0	2,0	50		-	BNC/ SMA	
ANT-2-350-30 «            »	350	10	2,0	2,0	50		-	BNC/ SMA	
ANT-2-375-30 «            »	375	10	2,0	2,0	50		-	BNC/ SMA	
ANT-2-415-30	415	10	2,0	2,0	50		-	BNC/ SMA	

				( )					
« »									
ANT-2-450-30 « »	450	15	2,0	2,0	50		-	BNC/ SMA	
ANT-2-620-30 « »	620	20	2,0	2,0	50		-	BNC/ SMA	
ANT-2-920-30 « »	920	30	2,0	2,0	50		-	BNC/ SMA	
ANT-3-1000-100	1000	100	2,0	1,5	50		-	BNC/ SMA/N	
ANT-3-1500-100	1500	150	2,0	1,5	50		-	BNC/ SMA/N	
ANT-3-2400-100	2400	240	2,0	1,5	50		-	BNC/ SMA/N	
ANT-3-3500-100	3500	350	2,0	1,5	50		-	BNC/	

				( )					°
								SMA/N	
ANT-3-5700-100	5700	570	2,0	1,5	50		-	BNC/ SMA/N	
ANT-4-415-30	415	30	4,0	2,0	50		3,0	BNC/ SMA/N	180°
ANT-4-1000-100	1000	100	8,0	2,0	50		6,0	BNC/ SMA/N	120°
ANT-4-1500-100	1500	100	8,0	2,0	50		8,0	BNC/ SMA/N	120°
ANT-4-2400-100	2400	100	10,0	2,0	50		10,0	BNC/ SMA/N	90°
ANT-4-3500-100	3500	100	12,0	2,0	50		12,0	BNC/ SMA/N	90°
ANT-4-5700-100	5700	100	12,0	2,0	50		16,0	BNC/ SMA/N	70°

				( )					
ANT-5-400-40	400	10	4,5	1,5	50			BNC/ SMA/N	
ANT-5-315-10	315	10	4,5	1,5	50			BNC/ SMA/N	
ANT-5-915-10	915	30	4,5	1,5	50			BNC/ SMA/N	
ANT-5-1000-100	1000	30	4,5	1,5	50			BNC/ SMA/N	
ANT-5-1100-100	1100	30	4,5	1,5	50			BNC/ SMA/N	

	，	，	，	（	，		，	，	°
ANT-5-1450-100	1450	40	4,5	1,5	50			BNC/ SMA/N	
ANT-5-1900-100	1900	60	4,5	1,5	50			BNC/ SMA/N	
ANT-6-1050-100	1050	100	0	2,0	50		-6,0	SMA	360 <sup>0</sup>
ANT-6-1150-100	1150	100	0	2,0	50		-6,0	SMA	360 <sup>0</sup>
ANT-6-1450-100	1450	100	0	2,0	50		-6,0	SMA	360 <sup>0</sup>
ANT-7-1050-100	1050	100	0	2,0	50		-6,0	SMA	180 <sup>0</sup>

				( )					°
ANT-7-1150-100	1150	100	0	2,0	50		-6,0	SMA	180 <sup>0</sup>
ANT-7-1450-100	1450	100	0	2,0	50		-6,0	SMA	180 <sup>0</sup>
ANT-8-1050-100	1050	100	0	2,0	50			BNC/ SMA/N	360 <sup>0</sup>
ANT-8-1150-100	1150	100	0	2,0	50			BNC/ SMA/N	360 <sup>0</sup>
ANT-8-1450-100	1450	100	0	2,0	50			BNC/ SMA/N	360 <sup>0</sup>
ANT-8-1800-100	1800	100	0	2,0	50			BNC/ SMA/N	360 <sup>0</sup>

				( )					°
ANT-9-1050-100	1050	100	8,0	2,0	50		6,0	BNC/ SMA/N	90 <sup>0</sup>
ANT-9-1150-100	1150	100	8,0	2,0	50		6,0	BNC/ SMA/N	90 <sup>0</sup>
ANT-9-1450-100	1450	100	8,0	2,0	50		10,0	BNC/ SMA/N	80 <sup>0</sup>
ANT-10-1050-100	1050	100	8,0	2,0	50		6,0	BNC/ SMA	90 <sup>0</sup>
ANT-10-1150-100	1150	100	8,0	2,0	50		6,0	BNC/ SMA	90 <sup>0</sup>

				( )					°
ANT-10-1450-100	1450	100	8,0	2,0	50		6,0	BNC/ SMA	80°
ANT-10-2400-100	2400	100	8,0	2,0	50		6,0	BNC/ SMA/	80°
ANT-11-315-10	315	15	2,0	1,5	50			BNC/ SMA	
ANT-11-400-40	400	20	2,0	1,5	50			BNC/ SMA	
ANT-11-900-100	900	45	2,0	1,5	50			BNC/ SMA	

	，	，	，	（	，		，	，	—
ANT-11-1050-100	1050	50	2,0	1,5	50			BNC/ SMA	
ANT-11-1150-100	1150	60	2,0	1,5	50			BNC/ SMA	
ANT-11-1450-100	1450	70	2,0	1,5	50			BNC/ SMA	
ANT-11-1800-100	1800	90	2,0	1,5	50			BNC/ SMA	
ANT-11-2400-100	2400	120	2,0	1,5	50		15	BNC/ SMA	

ANT-12-400-40	400	40	10,0	1,5	50		15	BNC/ SMA	
ANT-12-900-50	900	50	10,0	1,5	50		15	BNC/ SMA	
ANT-12-915-10	915	50	10,0	1,5	50		15	BNC/ SMA	
ANT-12-800-100	800	50	10,0	1,5	50		15	BNC/ SMA	
ANT-12-1050-100	1050	100	10,0	1,5	50		15	BNC/ SMA	

				( )					
ANT-12-1150-100	1150	100	10,0	2,0	50		16	BNC/ SMA	
ANT-12-1450-100	1450	100	10,0	2,0	50		18	BNC/ SMA	
ANT-12-1900-100	1900	100	12,0	2,0	50		20	BNC/ SMA	
ANT-12-2400-100	2400	100	12,0	2,0	50		20	BNC/ SMA	
ANT-12-3500-100	3500	100	13,0	2,0	50		20	BNC/ SMA	

				( )					
ANT-12-5700-100	5700	100	14,0	2,0	50		20	BNC/ SMA	
ANT-13-400-40	400	40	10,0	1,5	50		15	BNC/ SMA	
ANT-13-800-50	800	50	10,0	1,5	50		15	BNC/ SMA	
ANT-13-915-10	915	50	10,0	1,5	50		15	BNC/ SMA	
ANT-13-1050-100	1050	100	10,0	1,5	50		15	BNC/ SMA	
ANT-13-1150-100	1150	100	10,0	2,0	50		16	BNC/ SMA	
ANT-13-1450-100	1450	100	10,0	2,0	50		18	BNC/ SMA	

	，	，	，	（	，		，	，	—
ANT-13-1900-100	1900	100	12,0	2,0	50		20	BNC/ SMA	
ANT-13-2400-100	2400	100	12,0	2,0	50		20	BNC/ SMA	
ANT-13-3500-100	3500	100	13,0	2,0	50		20	BNC/ SMA	
ANT-13-5700-100	5700	100	14,0	2,0	50		20	BNC/ SMA	
ANT-14-400-40 «                    »	400	40	8,0	1,5	50		20	BNC/ SMA	
ANT-14-900-100	900	40	10,0	1,5	50		20	BNC/ SMA	

				( )					
« »									
ANT-14-800-100 « »	800	40	10,0	1,5	50		20	BNC/ SMA	
ANT-14-915-10 « »	915	40	10,0	1,5	50		20	BNC/ SMA	
ANT-14-1050-100 « »	1050	40	11,0	1,5	50		22	BNC/ SMA	
ANT-14-1150-100 « »	1150	40	11,0	1,5	50		22	BNC/ SMA	
ANT-14-1450-100	1450	40	14,0	1,5	50		23	BNC/ SMA	

	，	，	，	（	，		，	，	—
«                    »									
ANT-14-1900-100 «                    »	1900	40	15,0	1,5	50		25	BNC/ SMA	
ANT-14-2400-100 «                    »	2400	40	15,0	1,5	50		25	BNC/ SMA	
ANT-14-3500-100 «                    »	3500	40	15,0	1,5	50		25	BNC/ SMA	
ANT-14-5700-100 «                    »	5700	40	15,0	1,5	50		25	BNC/ SMA	
ANT-15-400-40 «                    »	400	40		1,5	50		20	BNC/ SMA	

ANT-15-900-100 «                    »	900	40		1,5	50		20	BNC/ SMA	
ANT-15-800-100 «                    »	800	40		1,5	50		20	BNC/ SMA	
ANT-15-915-10 «                    »	915	40		1,5	50		20	BNC/ SMA	
ANT-15-1050-100 «                    »	1050	40		1,5	50		22	BNC/ SMA	
ANT-15-1150-100 «                    »	1150	40		1,5	50		22	BNC/ SMA	
ANT-15-1450-100 «                    »	1450	40		1,5	50		23	BNC/ SMA	
ANT-15-1900-100 «                    »	1900	40		1,5	50		25	BNC/ SMA	

ANT-15-2400-100 «                    »	2400	40		1,5	50		25	BNC/ SMA	
ANT-15-3500-100 «                    »	3500	40		1,5	50		25	BNC/ SMA	
ANT-15-5700-100 «                    »	5700	40		1,5	50		25	BNC/ SMA	
ANT-16-100	30...100				50			BNC/ SMA	
ANT-16-1000	100...1000				50			BNC/ SMA	
ANT-16-2000	800...2000				50			BNC/ SMA	

ANT-16-3000	50...3000				50			BNC/ SMA	
ANT-16-4000	50...4000				50			BNC/ SMA	
ANT-3-25-50	22,5	15	1.5	2	50			N -	
ANT-3-25-75	22,5	15	1.5	2	75			N -	
ANT-15-25-50 «                    »	25	20	3	2	50			N -	45
ANT-15-25-50 «                    »	25	20	3	2	50			N -	45

				( )					3
ANT-17-400-50	400	400	8	2	50			SMA	25
ANT-17-1000-50	1000	1000	6	2.5	50			SMA	20
ANT-17-2500-50	2500	1000	6	3	50			SMA	25
ANT-18-500-50	600	800	2	2	50			SMA	
ANT-18-2000-50	2000	2000	1,5	2	50			SMA	
ANT-19-10G-10-50	10000	18000	15-40	2.5	50			N-SMA	1.5-20
ANT-19-10G-5-50	10000	18000	10-25	2.5	50			N-SMA	3 – 40

				( )					
ANT-19-10G-10-75	10000	18000	15-40	2.5	75			N-SMA	1.5-20
ANT-19-10G-5-75	10000	18000	10-25	2.5	75			N-SMA	3 – 40